

PROGRAMMING GUIDE FOR WIRELESS UNITS ON HYOSUNG

(FLIP OVER FOR GENMEGA/HANTLE/TRANAX MACHINES)

For TCP/IP Connection via Cat5 Cable

Verify Cat5 Cable is securely connected between ATM and Wireless Unit
 Log into Operator Function screen using **Master Password**
 Enter **Customer Setup > Select Processor > TCP/IP Type**

Cardtronics	VISA FRAMED TCP/IP
Columbus Data	STANDARD TCP/IP
DNS	STANDARD TCP/IP
EFX	STANDARD OR VISA FRAMED TCP/IP
ELAN / Genpass	VISA FRAMED TCP/IP
1 st ISO	STANDARD OR VISA FRAMED TCP/IP
Metavante / PAI / FIS	STANDARD TCP/IP
Switch Commerce	VISA FRAMED TCP/IP
Universal Money	STANDARD TCP/IP

****YOU MUST DISABLE SSL****Go back to **System Setup > Terminal IP > Disable DHCP**

Terminal IP Address	192.168.1.91 (RMS Users = 192.168.1.100)
Subnet Mask	255.255.255.0
Gateway	192.168.1.90
DNS	8.8.8.8

Go back to **Host Setup > Host Address > Disable URL**Host IP Address #1 and #2: **192.168.1.90**Host Ports #1 and #2: **(see Port column below)**

Processor	Ports	Phone #1*	Phone #2*
Cardtronics	7004	18664036747	18664036745
Columbus Data	7000 or 7006	18664334608	18669233608
DNS	561 or 562	18008165409	18008165410
EFX	447	18558711292	18666496124
ELAN / Genpass	7002	18004726210	2222
1 st ISO	8444	18779991309	18005304784
Metavante / PAI / FIS	450	18008837723	18669564590
Switch Commerce	7003	18009318497	18009316030
Universal Money	4443 or 453	18003480574	18003480574

*For successful **Terminal ID Capture** via our device monitoring portal:
 YOU MUST PROGRAM THE ATM AS SHOWN ABOVE AND YOU MUST HAVE COMM
 HEADER ENABLED EVEN IF IT IS NOT REQUIRED BY YOUR PROCESSOR*

PROGRAMMING GUIDE FOR WIRELESS UNITS ON GENMEGA/HANTLE/TRANAX

(FLIP OVER FOR HYOSUNG MACHINES)

For TCP/IP Connection via Cat5 Cable

Verify Cat5 Cable is securely connected between ATM and Wireless Unit
 Log into Operator Function screen using **Master Password**
 Enter **Customer Setup > Change Processor > Communication**

Cardtronics	VISA FRAMED TCP/IP
Columbus Data	STANDARD TCP/IP
DNS	STANDARD TCP/IP
EFX	STANDARD OR VISA FRAMED TCP/IP
ELAN / Genpass	VISA FRAMED TCP/IP
1 st ISO	STANDARD OR VISA FRAMED TCP/IP
Metavante / PAI / FIS	STANDARD TCP/IP
Switch Commerce	VISA FRAMED TCP/IP
Universal Money	STANDARD TCP/IP

Go back to **System Setup > Device Setup > ATM TCP/IP Setup > TCP/IP Mode: Static**

Terminal IP Address	192.168.1.91 (RMS Users = 192.168.1.100)
Subnet Mask	255.255.255.0
Gateway	192.168.1.90
DNS	8.8.8.8

****YOU MUST HIT APPLY****Go back to **Host Setup > Host IP Address**Host IP Address #1 and #2: **192.168.1.90**Host Ports #1 and #2: **(see Port column below)**

Processor	Ports	Phone #1*	Phone #2*
Cardtronics	7004	18664036747	18664036745
Columbus Data	7000 or 7006	18664334608	18669233608
DNS	561 or 562	18008165409	18008165410
EFX	447	18558711292	18666496124
ELAN / Genpass	7002	18004726210	2222
1 st ISO	8444	18779991309	18005304784
Metavante / PAI / FIS	450	18008837723	18669564590
Switch Commerce	7003	18009318497	18009316030
Universal Money	4443 or 453	18003480574	18003480574

*For successful **Terminal ID Capture** via our device monitoring portal:
 YOU MUST PROGRAM THE ATM AS SHOWN ABOVE AND YOU MUST HAVE COMM
 HEADER ENABLED EVEN IF IT IS NOT REQUIRED BY YOUR PROCESSOR*